

Austral Fold Down Wall Mount Installation Instructions

Parts Supplied:

Qty. Description



- 2 Pre-Assembled side arms
- 2 Front Spacer Bar (4 for Add-A-Line)
- 1 Cord

1 x Accessory Bag:

- 2 16mm Plastic Caps for Braces
- 2 25mm Plastic Caps for tubing ends (4 for Add-A-Line)
- 1 Front Joiner Bar (2 for Add-A-Line)
- 1 Cord Knob (2 for Add-A-Line)
- 1 Cord Tidy (2 for Add-A-Line)

WALL MOUNT INSTRUCTIONS:

1. Use the Template supplied to mark the position of the drill holes.
 Place the Wall Bracket's top fixing screw approximately 50mm above user's head height or, for a general installation 1800mm above finished ground level. Ensure Template is vertically plumb. Drill both sets of holes.
Holes are to be drilled the following distance apart:
 - Standard, Compact, Add-A-Line and Slenderline 16 – 2400mm apart.
 - Slenderline 20 – 3310mm apart
 - Unit Line – 1310mm apart
 - Indoor/Outdoor Line – 1200mm apart
2. Attach left Pre-Assembled Side Arm to wall using screws and plugs.
3. Assemble the Front Bar using one Front Spacer to each side of the Front Joiner (bar with Sticker). The hole on the end of each Bar has no relevance to the installation.
4. **For Add-A-Line:** Assemble both sets of front bars. The Front Joiner Bars are the larger tubing with Austral sticker – these are the same length. Lay the other 4 Spacer Bars alongside each other – **they are different lengths**. The two shorter Spacer Bars are for the smaller frame. The two longer Spacer Bars are for the larger frame.
5. Fit Front Bar(s) to the fixed Left Side Arm (after attaching to wall) and push the unsecured end of the Front Bar into the Right Side Arm before fixing to wall.
6. Fix the Right Pre-Assembled Side Arm to wall.
7. **Ensure all bolts are secure but not over tight.** Bolts should be loose enough to allow marginal finger movement. The Catches must move freely to allow the Braces to lock and unlock.
8. Lock the frame into the upright position. **For Add-A-Line put both frames up.** Slide the line tension lock(s) towards the front bend. Thread the Cord through the first hole nearest the bend, leaving about 30cm of extra line. Continue threading Cord through to the back. Slip the Cord Tidy (6mm black grommet) onto the line **BEFORE** threading the last hole. **N.B. For Add-A-Line:** For the smaller frame: thread from front to back through all 7 holes and finish as in Step 8 = 7 lines only. For the larger frame: thread from front to back through the first 8 holes = 8 lines only.
9. The larger hole on the small Add-A-Line frame and the Indoor/Outdoor line will hold the wire Braces in position.
10. Cut the Cord end leaving 10-15cm. Wrap line over the top of the side arm and knot several times to the inside of the frame before pushing the end through the Cord Tidy. Do not tie the Cord under the frame as line will not fold down as flat as intended. See Diagram.



11. Working from back to front, pull each length taut until you reach the Line Tension Lock. With the Lever on the Line Tension Lock raised, push the Cord through the hole under the lever, pulling until the Cord is taut. Lock the lever down into position. Wrap the line in and around the Line Tension Lock to secure. Reduce excess line to about 12cm. Slide Cord Knob onto line end. Knot the Cord end and pull Cord Knob down over the knot. See Diagram.
12. Fit plastic caps to front of Braces and ends of side arms.

TO LOWER LINE

- a) Position your hand on front Joiner
- b) Push the line up firmly to allow Catch clips (black lugs) to grip Braces.
- c) Lower frame down.

TO RAISE LINE

- a) Position your hand on front Joiner Bar
- b) Lift until Catches pass the top screws by approximately 1cm. If frame is raised too far, line will not lock in.
- c) Lower frame slowly and allow Catches to lock into position.